

KABEL

Wires permanently connected to the sensors:

Pt100/S1, Pt100/S3, Pt100/SG, Pt100/SS, Pt100/M1, Pt100/Z, Pt100/P, Pt100/R, Pt100/S.

